## **HD-MA Image Comparison System**

with Customer Management System

## **User's Manual**

System requirement: a. IBM compatible PC

b. CPU: P4; 40G HDD 1.5G Hz or up


c. RAM: 512M above


d. VGA memory: 32M or above


Required OS: Windows XP, VISTA, 7 & 8

## **Software Installation**

Insert the software CD-R into the CD-ROM drive, select the language version you need to start installation.








1<sup>st</sup> entry the software, please make sure the main unit connect to computer and powered on. You should input the private password (regist code) for your right unit. (\* The regist code is on the sticker of software CD.)



\* After then, double click "HD-MA" icon on the screen (desktop) of PC to enter system every time.










There will be an error message for wrong regist code. Please check again and input the correct regist code in order to enter the software.





Please press with the right mouse on "HD-MA" icon, then select the "*Properties*" item.










































2 frame (left and right) picture comparison analysis



Click "3D" to start negative film function to facilitate analysis



Previous **④** □ 3D

On the selected red frame you are able to see a large part by clicking " icon. To return it to original size, please click the left mouse once.

